

### **SMARTCOM<sup>3</sup> CONTROL PANEL** & WARM AIR WIRING INTERCONNECTS.



#### Warnings

All external wiring MUST comply with the current IEE wiring regulations. These instruction MUST be used in conjunction with the SmartCom user manual and the appropriate heater manual.

Visit our Support Database at www.s-i-d.co.uk



Nortek Global HVAC (UK) Limited, Fens Pool Avenue, Brierley Hill, West Midlands, DY5 1QA

**INDEX** 

	Diagram Number(s)			
	Heater type	Single Stage	Two Stage	Modulation
	UESA (all versions) UDSA-3* (025-100) *from Jan14 UDSA-4** (055-085) **from Sept 15 VRA-3*** (12-145) ***after s/no.154501956	1	2	3
	UDSA UDSA-2 UDSA-3 (008-020) UDSA-3* (025-100) *prior to Jan14 VRA-3** (12-145) **prior to s/no.154501956 UPA LCSA	4	5	6
*Based	SDH SHH	7	8	9
	OUHA	10	11	-
	ULSA	-	-	18
	ST-2 series UC series c/w Autospark ignition	12	13	14
	UC series c/w Thermoelectric (P/Pilot)	15	16	17

# **1** Single Stage (on/off) Heaters with BMBC Autospark ignition to remote SmartCom<sup>3</sup> SZ.



### 2 Two Stage (hi/low) Heaters with BMBC Autospark ignition to remote SmartCom<sup>3</sup> MZ (or Network).



### 3 Modulation Heaters with BMBC Autospark ignition to remote SmartCom<sup>3</sup> MZ (or Network).



### 4 Single Stage (on/off) Heaters with Autospark ignition to remote SmartCom<sup>3</sup> SZ.



### 5 Two Stage (hi/low) Heaters with Autospark ignition to remote SmartCom<sup>3</sup> MZ (or Network).



### 6 Modulation Heaters with Autospark ignition to remote SmartCom<sup>3</sup> MZ (or Network).



### 7 Single Stage (on/off) SDH/SHH Heaters, Autospark ignition to remote SmartCom<sup>3</sup> SZ.



# 8 Two Stage (hi/low) SDH/SHH Heaters, Autospark ignition to remote SmartCom<sup>3</sup> MZ (*or* Network).



#### 9 Modulation SDH/SHH Heaters, Autospark ignition to remote SmartCom<sup>3</sup> MZ (or Network).



#### **10 Single Stage (on/off) OUHA Heaters with Autospark** to remote SmartCom<sup>3</sup> SZ.



### 11 Two Stage (hi/low) OUHA Heaters with Autospark Ignition to remote SmartCom<sup>3</sup> MZ (*or* Network).



### 12 Single Stage (on/off) ST Heaters with Autospark to remote SmartCom<sup>3</sup> SZ.



### 13 Two Stage (hi/low) ST Heaters with Autospark Ignition to remote SmartCom<sup>3</sup> MZ (or Network).



### 14 Modulation ST Heaters with Autospark ignition to remote SmartCom<sup>3</sup> MZ (or Network).



### 15 Single Stage (on/off) Heaters with Thermoelectric (permanent pilot) to remote SmartCom<sup>3</sup> SZ.



### 16 Two Stage (hi/low) Heaters with Thermoelectric (permanent pilot) to remote SmartCom<sup>3</sup> MZ (or Network).



### 17 Modulation Heaters with Thermoelectric (permanent pilot) to remote SmartCom<sup>3</sup> MZ (or Network).



### **18 Modulation ULSA Heaters with Autospark ignition** to remote SmartCom<sup>3</sup> MZ.



Registered in England No. 1390934. Registered office: 10 Norwich Street, London, EC4A 1BD

Nortek Global HVAC is a registered trademark of Nortek Global HVAC Limited. Because of continuous product innovation, Nortek Global HVAC reserves the right to change product specification without due notice.